

PORTABOOM® PB2000 MAINTENANCE CHECKLIST



MODEL No: _____ UNIT No: _____ DATE INSPECTED: _____

Checklist Items	
Chassis Free from damage	
Stability Legs in good working condition including wing nuts and bolts	
Check Stability Legs ensuring a secure fit and storage	
Both brakes in good working order and free of sand	
Both Front and Rear wheels in good working order and free of sand	
Small panel free of damage and locks securely	
Large panel free from damage and locks securely	
Tighten billet nuts and bolts on boom arm	
Attach Boom Arm to Unit and check extension of arm and securing by way of tightening of wing nuts x2	
Ensure all connectors to circuit board are secure	
Ensure 240V connection is secure	
Antenna free from damage	
Check to ensure all nuts on the spring mechanism are tight	
Check that the "R" clip is locked into place	
Check On/Off switch for operation ensuring Green LED is illuminated when the Unit is turned On	
Check manual push button operation Up/Down/Stop	
Check both remotes operation Up/Down/Stop ensuring Green and Red LEDS illuminate to spec	
Check that the Blue LED illuminates when charging using the 240V connection	
Check battery charger indicators are illuminated and charging as per specification	
Check bounce back operation ensuring Arm returns to OPEN position when striking an object	
Ensure both remotes are working and free from damage	
Check both remotes are clearly labelled with unit number	
Check to ensure carry bag is in good condition	
Check key tag is attached to carry bag and labelled with correct unit number	
Check carry bag contains unit number magnet, 2x remotes, and key to small panel	
Ensure all mechanical bolts and screw are securely tightened	
Ensure all battery, 12V, 240V, Charger, Circuit board wiring is secure	
Attach Completed Maintenance Checklists to Unit Asset Number in WSP	

PORTABOOM® PB2000 MAINTENANCE CHECKLIST



COMMENTS

PORTABOOM Maintenance carried out by:-

PRINT NAME:

SIGN:

DATE: